

Operating Instructions



Hotdog Roller

Safety Note: To avoid severe burns, do not touch the cooking surface when hot.

1. Place your hot dog grill on a sturdy table or surface protected from the elements.
2. Plug the unit into any grounded electrical outlet.
3. Place hotdogs, sausages, or bratwurst on the rollers.
4. Turn the temperature knob to the desired temperature (low, medium, or high) for each cooking surface you wish to use (5 front rollers and/or five rear rollers)

**A hot dog should take between 10 and 12 minutes to cook.
This grill can accommodate 18 hot dogs at one time.**

**For any questions or concerns, be sure to contact us immediately.
Thank you for your business!**

1155 Route 9
Wappingers Falls, NY
(845) 298-0011



1 Precision Road
Danbury, CT
(203) 744-2295