



Sno-Kone



Your Premier Party Rental Company

Operating Instructions

1155 Route 9, Wappingers Falls, NY (845) 298-0011
1 Precision Road, Danbury, CT (203) 744-2295
20 Putnam Drive, Cheshire, CT (203) 250-6600

1. Place this machine on a sturdy surface.
2. Plug this unit into a dedicated 15 amp outlet.
3. Fill the gooseneck with ice cubes or block ice. If using block ice, break into 3" or 4" pieces. Fill to about an inch or so from the top. (The larger the piece of ice the better the snow.) Turn on motor and hold red shave button.
4. Push the handle down so that the ice presses against the cutter head. A firm even pressure is all that is required. You may need to relieve the pressure two or three times on the way down.

****Too much pressure on the pusher handle will make the snow come out coarse; too little pressure makes the ice mushy.****

5. Scoop the ice into a sno-kone cup and add the flavor of your choice. Enjoy.

NOTE : This machine will shave 300-500 pounds of ice per hour. 100 pounds of ice equals to 300 servings, and 5 pounds of ice equals 15 servings.

****Do not let any metal get down into the gooseneck or you will ruin the blades. ****

****Never put hands into gooseneck while machine is running-unplug first. ****

****Never leave this machine unattended while plugged in.****

If you have any questions or concerns please contact us immediately.

Thank you for your business.

www.durantsparty.com