



DURANT'S PARTY RENTALS

Your Premier Rental Company

Coffee Urns



Operating Instructions

1155 Route 9, Wappingers Falls, NY (845) 298-0011
1 Precision Road, Danbury, CT (203) 744-2295
20 Putnam Drive, Cheshire, CT (203) 250-6600

Service Note: This unit draws more amperage than any appliance in your kitchen. Please use a dedicated 20-amp outlet

1. Remove top, basket, and wand from inside the urn.
2. Fill with cold water to desired line depending on the amount of coffee you would like to brew.
3. Replace wand and basket inside urn.
4. No paper filter is needed for this machine. Use the basket as your filter and pour dry coffee inside basket.
5. Replace top and plug into a dedicated 20-amp circuit. (Do not plug anything else into the outlet or the unit will not work.) Make certain this circuit does not have other outlets on it. **The coffee pot needs all 20 amps.**
6. Allow 1 hour for brewing time. (Brews at approximately 1 cup per minute).

Clean up:

Rinse out all instruments when finished. Cleaning the coffee maker is not necessary. Just rinse off extra coffee debris.

2 cups dry coffee makes 30 brewed cups 6 cups makes 90 brewed cups
One pound of coffee is approximately 4 ³/₄ measured cups.

If you have any problems with this unit, contact us immediately.

845-298-0011 or 203-744-2295

Thank you for your business

www.durantsparty.com