



DURANTS PARTY RENTALS

Your Premier Party Rental Company

1155 Route 9, Wappingers Falls, NY (845) 298-0011
1 Precision Road, Danbury, CT (203) 744-2295

Ice Cream Cart



Operating Instructions

1. Please use a dedicated 20-amp outlet.
2. Plug in the freezer 24 hours before storing the product.
3. When the frost builds up on the walls and the holding plates, scrape off periodically. Ice acts as an insulator, preventing cold from coming through.
4. If you should unplug the freezer, you must allow it to sit for one hour before you plug it back in. This will prevent short cycling and burning out of the compressor.
5. If power is not available at the site, the freezer will maintain temperature for 5 hours, depending on outside temperature and frequency of door opening.

Caution:

- Never drill into any wall surface on the freezer.
- Never block compressor vents or block air circulation.
- Do not touch any thermostat controls or dials.

If you have any questions or concerns, be sure to get in touch with us immediately

845-298-0011 or 203-744-2295

Thank you for your business.

www.durantsparty.com