



**DURANT'S
PARTY RENTALS**

Your Premier Party Rental Company

1155 Route 9, Wappingers Falls, NY (845) 298-0011
1 Precision Road, Danbury, CT (203) 744-2295

Dunk Tank



Be sure to review ALL safety rules before use.

You must always have adult supervision when the tank is in use.

Never leave a dunk tank filled with water un-attended

Cordon off a “danger zone” in front, sides, and behind the tank. Keep people out of the zone to avoid getting hit by an errant or deflected throw. **Children should never be allowed inside this “danger zone.”**

You must be at least 5 feet tall and no more than 250 pounds to enter the tank.

No Non swimmers in dunk tank.

Keep dunk tank away from electricity.

Keep water level at least 8” away from the top of the tank.

Only one person is on the seat and never stands on the seat.

Before each use, make sure the seat is securely locked in place, and the safety latch is engaged.

Always wear rubber sole shoes to keep from slipping.

Advise participants to move towards the front of the tank to avoid hitting their head on the seat when coming out of the water.

Do not operate a dunk tank during a storm.

Never use baseballs or other hard balls on the tank. Do not hit the target with your hands.

Note: When filled tank weighs over 4,500 pounds

1. Select a level area for set-up.
2. Slowly lift and set tank upright.
3. Swing gate wing from its stored position to be perpendicular with the tank.
4. Lower the stabilizing rod on the bottom of the wing, so the wind does not move it, as this will cause the trigger arm to jam.
5. Check the drain plug to make sure it is tight, and then fill it with water.
6. Place the flattened end of the arm into the trigger mechanism. Put the other end through the square tubing on the wing and the hole in the canvas. Make sure the arm drops into the slot on the side of the frame.
7. Insert the target into the end of the arm, so the pinholes line up. Insert the clip pin.
8. Place one hand on the front of the seat and push down. On the other hand, test the target to see that it works properly.
9. You can adjust the difficulty by positioning the arm slightly closer or slightly further from the ball thrower.

Takedown:

1. Remove the drain plug and let the tank empty. Replace plug.
2. Fold the wing against the side of the unit and securely tie it off.
3. Place the seat in the “up” position and lock.

If you have any questions or concerns, be sure to contact us immediately.

845-298-0011 or 203-744-2295

Thank you for your business.
www.durantsparty.com