



# DURANT'S PARTY RENTALS

*Your Premier Party Rental Company*

1155 Route 9, Wappingers Falls, NY (845) 298-0011  
1 Precision Road, Danbury, CT (203) 744-2295

## Fog Machine



### Operating Instructions

1. Place the remote control at a convenient spot.
2. To avoid the risk of electrical shock, insert the power cord into a grounded outlet only.
3. Fill the reservoir with recommended Fog Fluid (this may already be filled).
4. Close cap tightly. Push clear plastic feeder tube down through the cap (if slack).
5. Allow approximately 7 minutes for a warm-up time.
6. When the indicator light on the controller goes on, the machine is ready for use.
7. At times the indicator light will go off. This is normal. The machine is simply recycling. Depress the switch only when the indicator light is on.
8. To use timer mode, press the "Timer" button. Adjust the "Duration" knob for the length of the fog burst. Adjust the "Interval" knob for the length of time between fog bursts.
9. When finished, allow the fog machine to cool down before packing for transportation.

#### **\*\*Caution:**

- Ensure that there is enough fog fluid in the tank before turning the fog machine on. Activating the pump without fluid can cause damage to the pump and heat core.
- Vapor from this fluid may be irritating to people with allergic sensitivity. Do Not expose at close range to a known asthmatic.
- Use in a well-ventilated area.
- To avoid injury from hot steam, keep at least two feet away from the nozzle.

If you have any questions or concerns, be sure to contact us immediately.

845-298-0011 or 203-744-2295

Thank you for your business.  
[www.durantsparty.com](http://www.durantsparty.com)