



DURANT'S PARTY RENTALS

Your Premier Party Rental Company

1155 Route 9, Wappingers Falls, NY (845) 298-0011

1 Precision Road, Danbury, CT (203) 744-2295

Operating Instructions



Note: Always follow all safety instructions affixed to this unit. Always obey local codes when using this oven.

CONVECTION OVEN INSTRUCTIONS

1. Turn the propane valve at the tank on *very* slowly. (This step is where most problems are caused!)
2. Make sure the oven is plugged in.
3. Make sure doors are closed
4. Push blue switch (blower) to on.
5. Push red switch (cool down) to auto
6. Set temperature knob to the desired setting
7. You will hear a sparking sound. The oven is attempting to light the pilot.
8. It will not light on the first attempt
9. It may be necessary to repeat several times

For any questions or concerns, be sure to contact us immediately.

845-298-0011 or 203-744-2295

Thank you for your business!

www.durantsparty.com