



DURANTS PARTY RENTALS

Your Premier Party Rental Company

1155 Route 9, Wappingers Falls, NY (845) 298-0011

1 Precision Road, Danbury, CT (203) 744-2295

Operating Instructions



This cabinet is meant to hold the temperature of heated foods. It is not designed nor intended to heat cold foods.

Make sure the cabinet is away from ventilation or cold drafts for best performance.

You will need a dedicated 20amp Outlet.

Allow a minimum of 30 minutes to reach the desired temperature.

This unit has two modes: Proofing and Holding. When the unit is in "HOLD" mode, the element in the water pan does not activate and creates the humidity needed for the proofing mode.

Proofing Mode Instructions

1. Fill the reservoir with DISTILLED water.
2. Push the "ON/OFF" switch to the "ON" position. The red indicator light will illuminate.
3. Pre-heat the cabinet. Push the "PROOF / HOLD" switch to the "HOLD" position.
4. Set the temperature control (marked temperature) to 7 or 8 to quickly heat the cabinet.
5. Upon temperature reaching 90°F – 100°F, push the "PROOF / HOLD" switch to the "PROOF" position.
6. Turn the temperature dial down and the humidity dial to 7 or 8. The 1000-watt element in the water pan is activated, and the water can become VERY hot! **DO NOT TOUCH THE WATER!**
7. Once the internal temperature in your desired range is met and the humidity begins to condense on the inside of the cabinet, maximum humidity has been reached. Setting the humidity any higher will only cause more water to condense and run down the cabinet's interior and drain out.
8. Turn temperature and humidity dials to the appropriate levels for your particular use.
9. Turn the switch to the "OFF" position when done.

Holding Mode Instructions

1. Push the "ON / OFF" switch to the "ON" position. The red indicator light will illuminate.
2. Push "PROOF / HOLD" switch to "HOLD" position.
3. Set the thermostat control (marked temperature) to 7 or 8, in the beginning, to quickly heat the cabinet. Then adjust to your desired temperature. Temperature is read on the digital thermometer located on the cabinet's front panel.
4. Turn to the "OFF" position when done.

For any questions or concerns, be sure to contact us immediately.

845-298-0011 or 203-744-2295

Thank you for your business!

www.durantsparty.com