



# DURANT'S PARTY RENTALS

*Your Premier Party Rental Company*

1155 Route 9, Wappingers Falls, NY (845) 298-0011  
1 Precision Road, Danbury CT (203) 744-2295

**HAND WASHING STATION**



## **Operating Instructions**

**Note:** Always follow all safety instructions affixed to this unit.

1. Place the unit on a flat level surface.
2. Fill the water tank by unhooking the hook located in the upper right-hand corner of the unit. Once unhooked, you will be able to see the tank.
3. Open the lid of the water tank and fill it with water. Replace the lid.
4. To activate the water flow, depress the foot pump. (This will create a steady stream of water to wash your hands with).
5. To place the soap in the container, locate the button behind the dispenser. Press the button, and the lid will detach itself, allowing you to place the soap inside. Once filled, reattach the lid, and soap will dispense as needed.
6. To put in paper towels: Insert key into the small white lock on the top of the towel compartment. This will give you access to the towel compartment.

## **Disposing of gray water:**

1. Using a pair of gloves, locate the drain plug found on the bottom left corner of the unit.
2. To dispose of the gray water, remove the plug and allow the water to flow out. Once the water container is empty, replace the plug.

If you have questions or concerns, please call us immediately.

845-298-0011 or 203-744-2295

Thank you for your business

[www.durantsparty.com](http://www.durantsparty.com)