



# DURANT'S PARTY RENTALS

*Your Premier Party Rental Company*

1 Precision Road, Danbury, CT (203) 744-2295  
1155 Route 9, Wappinger Falls, NY (845) 298-0011

**Wacky kidZone Combo**



**\*\*Be sure to pick a location free from overhead electrical power or telephone lines. The location should be free from trees that could damage or stain the inflatable. An unobstructed area should be maintained for 5 feet around and above the perimeter of the mini Bounce N' Dip \*\***

### **Operating Instructions:**

1. Ideally, this unit should be set up on a level lawn area. If you must set it up on asphalt or another hard surface, please place blankets or other padded materials beneath it.
2. **Unroll and position the inflatable and locate the two inflation tubes on the inflatable. This inflatable has two sections. One zipper and ONE flap need to be closed securely to ensure no escaped air that would prevent the inflatable from blowing up completely (One flap is located on the lower back near the blower, one zipper is located on the right under the slide).**
3. Place the blower in an area that is not in a direct pathway. Be sure that the blower is on a flat, dry surface free of leaves or debris.
4. Please find the two inflation tubes: one will connect to the blower, and the other tube gets tied off with the strap attached to it. Make sure that the tube strapped to the blower is on very securely.
5. Plug the blower into your dedicated 20 amp outlet. If an extension cord is needed, you must make sure that it is of industrial strength. The cord needs to be 50 feet or less. Stake down the inflatable in at least two opposite corners. Cover the stakes with a suitable material to protect children while using the inflatable.
6. Locate the on/off switch on the blower and turn it on. Inflation should take approximately 3 minutes. The blower must remain on for the time that the inflatable is occupied.

### Deflating:

1. Clean out any debris from the inside of the inflatable and turn off the blower.
2. Monitor inflatable as it deflates
3. Attempt to roll inflatable back up. (We realize this isn't easy!)

### **\*\*Cautions:**

- Keep the front of the inflatable clear and accessible at all times.
- Please monitor children while they are using the inflatable. The maximum capacity is six children, and they should all be close in weight
- Children should always remove shoes when entering the inflatable.
- You need to ensure that you have a dedicated outlet for this inflatable. It would be best not to plug anything else into the same outlet.
- ***Adult supervision is required at all times.***
- If the inflatable is not completely dry, please do not roll up. Inflate and let run until dry. On a sunny day, it should only take about ½ hour.

If you have any questions or concerns, please call us immediately  
845-298-0011 or 203-744-2295

Thank you for your business!  
[www.durantsparty.com](http://www.durantsparty.com)