Operating Instructions



Convection Oven

Be sure to follow all safety instructions affixed to this oven.

Place the unit on a sturdy table.

Plug this oven into a dedicated 20-amp outlet.

- 1. This oven features a timer that you may choose to use. If you wish, set the knob to the desired time, and the oven will shut off after the set time has elapsed.
- 2. Set the temperature knob to the desired temperature. Please note that the light indicates the heating element is on, and the light goes out when the desired temperature has been reached.
- 3. For finishing/browning, turn the temperature knob past 572° F to the symbol that resembles a fan.

Caution:

- Please be aware that this oven has hot surfaces.
- Use a potholder when removing pots.
- Keep children away from this oven.

For any questions or concerns, be sure to contact us immediately. Thank you for your business!

1155 Route 9 Wappingers Falls, NY (845) 298-0011



1 Precision Road Danbury, CT (203) 744-2295